

Accu-LABS INC.

4831 S. Whipple Avenue
Chicago IL 60632
Phone: 773.523.3100 Fax: 773.523.4008
www.accu-labs.com

A2LA Accredited ISO/IEC 17025:2005 Certificate # 2558.01

325 OxyEtch

Accu-Labs 325 OxyEtch is a white, granular, free-flowing peroxygen powder that is a mildly acidic micro-etch that provides consistent copper etch rates from a stable and active solution that can be sprayed or used in dip applications.

Make-Up (WARNING! Refer to MSDS and Handling Considerations prior to Make-Up)

Accu-Labs 325 OxyEtch is supplied as a single-component dry powder and is added to deionized water and sulfuric acid.

- Fill tank to approximately $\frac{3}{4}$ volume DI water
- Add 0.5%-2.0% sulfuric acid (1.84 s.g.)
- Add 1/8 to 1/2 pound per gallon 325 OxyEtch
- Note: Etch rate is dependant upon the 325 OxyEtch concentration, acid concentration, and temperature

DO NOT USE ANY ACID OTHER THAN SULFURIC ACID, AS TOXIC GASES MAY EVOLVE

Typical Bath Operation

- Dwell time is dependent upon the degree of etch desired, 1-5 minutes is typical
- Temperature 75°-85°F, etch rate will increase with temperature but will reduce bath life

Yield

- For etched depths of 10 microinches, a typical yield of approximately 400 square feet of copper surface per pound of 325 OxyEtch may be expected, as the copper content approaches 15 g/l, the bath may be discarded or chilled to remove copper sulfate. The solution may then be decanted, filtered, analyzed for A.O.C. and replenished.

Bath Control

- The etch rate of 325 OxyEtch is dependent upon the active oxygen content (A.O.C.) of the bath. Please refer to analysis and replenishment procedure.

A.O.C. Control Procedure

Reagents

- Sodium thiosulfate, 0.1N
- Potassium iodide/EDTA solution (dissolve 100 g KI and 20 g EDTA) into distilled water, add one drop ammonia dilute to 1 liter
- Starch indicator
- Degassed water

Procedure

- Pipette 2.0 ml 325 OxyEtch bath into 250 ml E-flask
- Add 100 ml degassed water and 10 ml potassium iodide/EDTA solution & mix thoroughly
- Titrate with sodium thiosulfate to pale yellow/green color
- Add starch indicator and titrate to virtual colorless end point

Calculation

$$\text{A.O.C. g/l} = \text{ml Na}_2\text{S}_2\text{O}_3 \times \text{N Na}_2\text{S}_2\text{O}_3 \times 8 / \text{sample size}$$

Replenishment

To raise A.O.C. 0.1 g/l add 0.4 oz/gal of 325 OxyEtch

Copper Control Procedure**Reagents**

- EDTA 0.05M
- Ammonium Acetate 20%
- Sodium Hydroxide Solution (350 g/l)
- Glacial acetic acid
- PAN indicator

Procedure

- Pipette 2.0 ml sample of 325 OxyEtch bath into 250 ml conical beaker
- Add sodium hydroxide while mixing until solution turns brown
- Bring to boil for 30 seconds until gassing ceases
- Add few drops DI water followed by glacial acetic acid until the copper oxide precipitate dissolves
- Add 10 ml ammonium acetate and dilute to 100 ml DI water
- Heat to 105° F and add 10 drops 0.1% PAN indicator, titrate with EDTA until pink color fades rapidly to a yellow-green

Calculation

$$\text{Copper g/l} = \text{ml EDTA} \times \text{M EDTA} \times 63.54 / \text{sample size}$$

HANDLING Wear eye protection and personal protective gear when working with or handling this material; refer to MSDS prior to use. Store material in a cool dry area away from other chemicals that are incompatible per the MSDS.

Disclaimer

The information in this document is believed to be correct, however no warranty of merchantability, fitness for any particular purpose, or any other warranty is express or is to be implied regarding accuracy or completeness of this information.