

ACCU-LABS INC.

4831 S. Whipple Avenue
Chicago IL 60632
Phone: 773.523.3100 Fax: 773.523.4008
www.accu-labs.com

A2LA Accredited ISO/IEC 17025:2005 Certificate # 2558.01

490 PATCLEAN BIODEGREASER

ACCU-LABS 490 PATCLEAN BIODEGREASER solvent is specifically formulated to conform to regulations regarding air and chemical pollutants. ACCU-LABS 490 PATCLEAN BIODEGREASER contains only biodegradable ingredients allowing for safe and easy disposal.

ACCU-LABS 490 PATCLEAN BIODEGREASER has proven to be an efficient, economical degreaser capable of superior solvency for effective removal of heavy greases, oils, sludges and oxidized films on most metals.

COMPOSITION

ACCU-LABS 490 PATCLEAN BIODEGREASER incorporates a natural organic hydrocarbon with emulsifying agents to form a unique, water-soluble degreasing compound.

ACCU-LABS 490 PATCLEAN BIODEGREASER contains no petroleum distillates or chlorinated solvents and is pleasantly fragrant.

ACCU-LABS 490 PATCLEAN BIODEGREASER is a water-soluble solvent degreasing compound with a high flash point. May be used in concentrate form for tenacious soils, but may be diluted with water for less soiled conditions.

APPLICATIONS

ACCU-LABS 490 PATCLEAN BIODEGREASER is recommended for use anywhere water rinse is permitted or desired.

Heavy oils, greases, dirt, grime, oil deposits, oxidized films, grease pits are all cleaned easily, economically, efficiently and ecologically safe with ACCU-LABS 490 PATCLEAN BIODEGREASER.

On mobile equipment, plant floors, pits, cellars, walls-in all industrial and general maintenance cleaning and degreasing operations ACCU-LABS 490 PATCLEAN BIODEGREASER will do the job and leave the work area with a refreshing odor.

ACCU-LABS 490 PATCLEAN BIODEGREASER is safe on all metals as well as unpainted and most painted surfaces.

For a safer environment, ACCU-LABS 490 PATCLEAN BIODEGREASER will replace those highly flammable and toxic solvents and caustic alkalis.

OPERATIONAL GUIDELINES:

DILUTION RATES

The following dilution rates are based on typical applications and may vary according to soil and surface conditions and the type of equipment used in the operation.

MANUAL OPERATIONS

Dilute concentrate with water at 1:4 to 1:20.

PRESSURE SPRAY METHOD

Dilute concentrate with water at 1:20

TANK IMMERSION METHOD

Mix concentrate with water at 1:4 to 1:10 depending on the degree of soil to be removed.

For extremely heavily soiled surfaces use ACCU-LABS 490 PATCLEAN BIODEGREASER concentrated or diluted with up to 3 parts water (1:3).

SAFETY

Always wear eye protection and personal protective gear when handling or working with this or any chemical product. Read MSDS prior to use.

DISCLAIMER

The information contained on this sheet is true and accurate to the best of our knowledge. Because use and conditions are beyond our control, no guarantee is expressed or implied for the above suggestions or recommendations. Accu-Labs, Inc. will not incur any liability in connection with the use of these suggestions and/or technical data.