

# ACCU-LABS INC.

4831 S. Whipple Avenue  
Chicago IL 60632

Phone: 773.523.3100 Fax: 773.523.4008

[www.accu-labs.com](http://www.accu-labs.com)

**A2LA Accredited ISO/IEC 17025:2005 Certificate # 2558.01**

## 205-JP ACID SALTS

**ACCU-LABS 205-JP Acid Salts** is a dry, free flowing compound formulated specifically for use in acid pickling of zinc die castings and zinc slush castings.

The use of this product is effective in removing smut and oxidation from zinc surfaces, leaving a clear finish, which accepts subsequent plated deposits with the best possible adhesion.

### OPERATING CONDITIONS

Concentration:	4 – 12 oz/gal
Temperature:	Room to 140°F
Optimum Conc. & Temp:	6 oz/gal at 120°F
Time:	10 – 60 seconds

### ANALYSIS PROCEDURE

20 ml sample in 250 ml flask  
Add 5 drops methyl orange indicator  
Titrate with 1.0N sodium hydroxide to yellow endpoint  
Titration mls x 0.9 = oz/gal acid salts

**MAKE-UP:** Fill tank two-thirds full with warm water. Add the necessary amount of 205-JP ACID SALTS with agitation. Continue stirring until all acid salts are dissolved.

**CAUTION:** 205-JP Acid Salts is acidic in nature and, when dissolved in water, becomes a mild acid solution. Contact of the salts or the salts solution with the skin or eyes should be avoided. In case of contact, flush eyes and skin with water and seek medical attention.

### NON-WARRANTY

*The information contained in this bulletin is, to the best of our knowledge true and accurate, but all recommendations or suggestions are made without guarantee, since the conditions of use are beyond our control. ACCU-LABS INC. disclaims any and all liability arising from the use of this product or the information contained herein.*